




Instruction Manual

DIRECT INSERTION TYPE ZIRCONIA OXYGEN ANALYZER

Type: ZSB



PREFACE

We are grateful for your purchase of Fuji Direct Insertion Type Zirconia Oxygen Analyzer (ZSB).

- First read this instruction manual carefully until an adequate understanding is acquired, and then proceed to installation, operation and maintenance of the analyzer. Wrong handling may cause an accident or injury.
- The specifications of this analyzer will be changed without prior notice for further product improvement.
- Modification of this analyzer is strictly prohibited unless a written approval is obtained from the manufacturer. Fuji will not bear any responsibility for a trouble caused by such a modification.
- This instruction manual shall be stored by the person who actually uses the analyzer.
- After reading the manual, be sure to store it at a place easier to access.
- This instruction manual should be delivered to the end user without fail.

Manufacturer: Fuji Electric Co., Ltd.
Type: Described in the nameplate put on the main body
Date of manufacture: Described in the nameplate put on the main body
Product nationality: Japan

- Related instruction manual
Direct insertion type zirconia oxygen analyzer detector (Type: ZFK8)..... INZ-TN5ZFK8-E
Direct insertion type zirconia oxygen analyzer converter (Type: ZKM) INZ-TN1ZKM-E

Request

- It is prohibited to transfer part or all of this manual without Fuji's permission in written format.
- Description in this manual will be changed without prior notice for further improvement.



©Fuji Electric Co., Ltd. 2009

Issued in June, 2009
Rev. 1st edition April, 2011



CAUTION ON SAFETY

First of all, read this “Caution on Safety” carefully, and then use the gas extractor in the correct way.

- Be sure to observe the instructions shown below, because they describe important information on safety. Those safety precautions are ranked in 3 levels, “DANGER”, “CAUTION” and “PROHIBITION”.

 DANGER	<p>Wrong handling may cause a dangerous situation, in which there is a risk of death or heavy injury.</p>
 CAUTION	<p>Wrong handling may invite a dangerous situation, in which there is a possibility of medium-level trouble or slight injury or only physical damage is predictable.</p>

- Even an undesirable action described in “  **CAUTION** ” may lead to a grave result depending on situation. Be sure to observe DANGER and CAUTION because they are both important for ensuring safety.

Caution on installation and transport of gas analyzer	
 DANGER	<ul style="list-style-type: none"> • This unit is not explosion-proof type. Do not use it in a place with explosive gases to prevent explosion, fire or other serious accidents.
 CAUTION	<ul style="list-style-type: none"> • This unit should be installed in a place which conforms to the conditions noted in the instruction manual. Otherwise, it may cause electric shocks, fire or malfunction of the unit. • During installation work, care should be taken to keep the unit free from entry of cable chips or other foreign objects. Otherwise, it may cause fire, trouble or malfunction of the unit. • For installation, observe the rule on it given in the instruction manual and select a place where the weight of gas analyzer can be endured. Installation at an unsuited place may cause turnover or fall and there is a risk of injury. • For lifting the gas analyzer, be sure to wear protective gloves. Bare hands may invite an injury. • Before transport, fix the casing so that it will not open. Otherwise, the casing may be separated and fall to cause an injury. • The gas analyzer is heavy. It should be transported carefully by two or more persons if manually required. Otherwise, body may be damaged or injured.

Caution on piping



DANGER

- If leaked gas contains oxygen at a high concentration, there is a risk of fire.
- Connect pipes correctly referring to the instruction manual. Wrong piping may cause gas leakage.

Caution on wiring



CAUTION

- The unit must be earthed as specified. Otherwise, it may cause electric shocks, malfunction, etc.
- Be sure to use a power supply of correct rating. Connection of power supply of incorrect rating may cause fire.
- Wiring work must be performed with the main power set to OFF to prevent electric shocks.
- Use wiring materials that match the rating of the unit. Use of wiring materials out of rating may cause fire.

Cautions on use



CAUTION

- During operation, avoid opening the casing and touching the internal parts. Otherwise, you may suffer a burn or shock hazard.
- Avoid touching the detector with bare hand during operation. Otherwise, you may suffer a burn because the detector may have reached a high temperature (about 800°C).
- During operation, avoid removing and placing the detector on or near a combustible material. Otherwise, fire may occur.

Caution on maintenance and check



- Before maintenance and check, be sure to turn off the main power supply and wait until the detector is cooled adequately. Otherwise, you may suffer a burn.
- Before removing the detector from the flue for maintenance and check, make sure the furnace is stopped. Otherwise, you may suffer a burn.
- Before working, take off a wrist watch, finger ring or the like metallic accessories. And never touch the instrument with a wet hand. Otherwise, you will have a shock hazard.
- If the fuse is blown, eliminate the cause, and then replace it with the one of the same capacity and type as before. Otherwise, shock hazard or fault may be caused.

Others



- If the cause of any fault cannot be determined despite reference to the instruction manual, be sure to contact your dealer or Fuji's technician in charge of adjustment. If the instrument is disassembled carelessly, you may have a shock hazard or injury.
- Do not use a replacement part other than specified by the instrument maker. Otherwise, adequate performance will not be provided. Besides, an accident or fault may be caused.
- Replacement parts such as a maintenance part should be disposed of as incombustibles.

CONTENTS

PREFACE	i
CAUTION ON SAFETY	ii
1. GENERAL DESCRIPTION	1
1.1 Direct insertion type zirconia oxygen analyzer	1
1.2 Check of delivered components	1
1.3 Check of the type of delivered components	2
2. NAME AND FUNCTION OF EACH PART	3
2.1 Name of major parts of the analyzer	3
2.2 Name and function of converter	4
2.3 Description on display/operation panel	5
3. INSTALLATION	6
3.1 Installation site	6
3.2 How to install the analyzer	6
3.3 Outline drawing of converter	8
4. WIRING AND PIPING	10
4.1 Before wiring	10
4.2 Wiring to each terminal	11
4.3 Wiring and piping diagram	12
4.4 Handling of standard gas	13
5. OPERATION	14
5.1 Preparation for operation	14
5.2 Key operation flow diagram (outline)	15
5.3 Initial parameter value table	19
6. PERATION START AND SHUTDOWN	23
6.1 Starting	23
6.2 Stopping operation	23
6.3 Actions during operation	24
6.4 Check the contents of display	25
6.5 Oxygen detector standard output voltage	27
7. CALIBRATION	28
7.1 Preparation	28

8. SETTING AND OPERATING OF PARAMETER.....	29
8.1 Measured menu	29
8.2 Manual calibration.....	37
8.3 BLOWDOWN (OPTION)	44
9. Maintenance menu.....	49
9.1 Error log display	49
9.2 Parameter menu	63
10. MAINTENANCE AND CHECK.....	84
10.1 Checking.....	84
10.2 Consumable parts	84
10.3 Spare parts	84
10.4 Replacement of fuse	85
10.5 Troubleshooting.....	86
11. SPECIFICATIONS.....	88
11.1 Specifications	88
11.2 Code symbols.....	91

1. GENERAL DESCRIPTION

This manual describes the installation, operation, and the maintenance of the zirconia oxygen analyzer. Read it carefully before using the analyzer. Refer to the instruction manual of the zirconia oxygen detector, type ZFK, for the handling of the detector used in combination with the analyzer.

1.1 Direct insertion type zirconia oxygen analyzer

The zirconia oxygen analyzer consists of a direct insertion type oxygen detector (type: ZFK) and a zirconia oxygen analyzer main unit.

The analyzer intended for the measurement of oxygen concentration in exhaust gas is used for combustion control.

Caution

Power voltage for the converter must conform to that for the detector to be connected. Don't use any power voltage different from the power specifications of the detector. Otherwise it may result in damage to the detector.

100/120V AC 50/60Hz for ZFK8R□1

200/240V AC 50/60Hz for ZFK8R□3

1.2 Check of delivered components

Check the appearance of the analyzer and the number of accessories to make sure that there is no damage or shortage of parts.

Delivered item (standard)

Zirconia oxygen analyzer: 1 set

Instruction manual: 1 copy

Standard accessories: 1 set

- O-ring (for detector): 1
- Ceramic filter (for detector): 1
- Fuse (2.5A, 0.5A): 2 each
- Joint (for standard gas connection): 1 set
- Polyethylene tube (for standard gas connection): 1
- Toaron tube (for standard gas connection): 1
- Flow guide tube accessories (bolt, nut, spring washer: 4 each): 1 set


1.3 Check of the type of delivered components

Check the model name on the rating plate to make sure that the delivered components are what you ordered.

1 2 3 4 5 6 7 8 - 9 10 11 12 13 14 15															Description		
Z	S	B															
4th digit			1													Converter mounting (4th digit)	
			2													Wall-mounting type (with indication window)	
																Self-stand type (with indication window)	
5th digit			A													Sensor, Power supply, Cal. Gas inlet (5th digit)	
			B													For general use without protection cover, 100/115 V AC, 50/60 Hz and inlet for $\phi 6$ mm tube	
																For general use with protection cover, 100/115 V AC, 50/60 Hz and inlet for $\phi 6$ mm tube	
																* Protection cover should be selected when ambient temperature is -10°C or lower.	
6th digit			Y													Sensor cable + calibration gas tube (6th digit)	
			A													None	
			B													6 m cable (without conduit) + 6 m Teflon tube ($\phi 6/\phi 4$)	
			C													10 m cable (without conduit) + 10 m Teflon tube ($\phi 6/\phi 4$)	
			D													15 m cable (without conduit) + 15 m Teflon tube ($\phi 6/\phi 4$)	
			E													20 m cable (without conduit) + 20 m Teflon tube ($\phi 6/\phi 4$)	
			F													6 m cable (with conduit) + 6 m Teflon tube ($\phi 6/\phi 4$)	
			G													10 m cable (with conduit) + 10 m Teflon tube ($\phi 6/\phi 4$)	
			H													15 m cable (with conduit) + 15 m Teflon tube ($\phi 6/\phi 4$)	
			J													20 m cable (with conduit) + 20 m Teflon tube ($\phi 6/\phi 4$)	
			K													6 m cable (4-core cable only. Heater cable should be prepared by customer.) + 6 m Teflon tube ($\phi 6/\phi 4$)	
			L													10 m cable (4-core cable only. Heater cable should be prepared by customer.) + 10 m Teflon tube ($\phi 6/\phi 4$)	
			M													15 m cable (4-core cable only. Heater cable should be prepared by customer.) + 15 m Teflon tube ($\phi 6/\phi 4$)	
																20 m cable (4-core cable only. Heater cable should be prepared by customer.) + 20 m Teflon tube ($\phi 6/\phi 4$)	
																* When exclusive-special conduit and heater cable are not used, the following conduit should be used. Conduit with outer diameter $\phi 23$ and inner diameter $\phi 16$ as specified in JIS C8411 For preparing two heater cables, their rating should be 3 A or more.	
7th digit			1													Calibration gas unit (7th digit)	
			2													Automatic calibration unit + zero gas + filter regulator	
			3													Automatic calibration unit + zero gas + air standard gas	
			4													Manual calibration unit + zero gas + filter regulator	
																Manual calibration unit + zero gas + air standard gas	
9th, 10th, 11th digits			0	Y	0											Flow guide tube (9th, 10th and 11th digit)	
			5	A	3											(Flange) (Application) (Length) (Note)	
			5	A	5											None None	
			5	A	7											SUS304 For general use 300mm	
			5	A	1											SUS304 For general use 500mm	
			5	B	3											SUS304 For general use 750mm	
			5	B	5											SUS304 For general use 1000mm	
			5	B	7											SUS316 For corrosive 300mm	
			6	D	3											SUS316 For corrosive 500mm	
			6	D	5											SUS316 For corrosive 750mm	
			6	D	7											SUS316 For corrosive 1000mm	
			6	D	1											SUS316 Without high particulate cover 300mm With blow-back unit	
			Z	Z	Z											SUS316 Without high particulate cover 500mm With blow-back unit	
			Z	Z	Z											SUS316 Without high particulate cover 750mm With blow-back unit	
			Z	Z	Z											SUS316 Without high particulate cover 1000mm With blow-back unit	
			Z	Z	Z											Others Others Others	
12th digit			B													Output signal (12th digit)	
			E													4 to 20mA DC	
																0 to 1V DC	
13th digit			J													Language (13th digit)	
			E													Japanese	
			C													English	
																Chinese	
14th digit			1													Communication functions (14th digit)	
			2													RS232	
																RS485	
15th digit			Y													Reference gas (15th digit)	
			1													None	
																$\phi 6$ mm tube joint	

2. NAME AND FUNCTION OF EACH PART


2.1 Name of major parts of the analyzer



Name of major parts of stand type analyzer


- (1) Converter
- (2) Toggle switch (Maintenance select switch)
- (3) Auto breaker
- (4) Relay block terminal
- (5) Port valve
- (6) Flow meter
- (7) Relay
- (8) External terminal block
- (9) Zirconia oxygen detector (ZFK8)
 - * Refer to the instruction manual of the zirconia oxygen detector (ZFK8) for the handling of the detector.
- (10) Regulator
- (11) Port valve
- (12) Filter regulator
- (13) Pressure controller
- (14) Standard gas (3.4L)

2.2 Name and function of converter



No.	Name	Explanation
(1)	CPU board	The liquid crystal display and the memory circuit are installed.
(2)	I/O board	The input/output circuit and the power circuit are installed.
(3)	Terminal block	Terminal block for various input/output signals.
(4)	Power switch	Turns ON/OFF this converter. (— : OFF, ○ : ON)
(5)	Tube type fuse (F2)	Fuse for the heater. (250 V T 2.5 A)
(6)	Tube type fuse (F1)	Fuse for the main unit (250 V T 0.5 A)
(7)	Display/operation panel	Displays or operates the concentration value or setting values.

2.3 Description on display/operation panel



No.	Name	Explanation
(1)	Display unit	Displays the concentration value and setting values.
(2)	MODE key	Used to switch measurement display and mode display.
(3)	ESC key	Used to return to the previous screen or exit the setting.
(4)	Digit key	Used to change the setting values.
(5)	Up key	
(6)	ENTER key	Used to determine the setting values.

3. INSTALLATION



CAUTION

- Install the analyzer securely and safely, paying attention not to let it fall.


3.1 Installation site

Install the analyzer in a place that satisfies the following conditions.

- (1) Space for periodic inspection and wiring work is available.
- (2) Vibration, dust, dirt, and humidity are minimal.
- (3) Not directly affected by radiation heat from heating furnace, etc. (converter)
- (4) The atmosphere is non-corrosive.
- (5) Away from electrical devices that may cause noise trouble (such as motor and transformer), and equipment that may cause electromagnetic or electrostatic induction trouble
- (6) Ambient temperature is -10 to $+50^{\circ}\text{C}$, and ambient humidity is 95%RH or lower. (converter)


3.2 How to install the analyzer

3.2.1 Stand type



No.	Name	Q'ty
(1)	Stand type converter	1
(2)	Anchor bolt (option) M12 × 160 × 50	4
(3)	M12 nut	4


3.2.2 Wall mount type



No.	Name	Q'ty
(1)	Wall-mount converter	1
(2)	Anchor bolt (option) M12 × 160 × 50	4
(3)	M12 nut	4

3.3 Outline drawing of converter


Wall-mount type



Front view


Right side view

Rear view



(BOX bottom view)

Stand type



4. WIRING AND PIPING



CAUTION



: Wiring work must be carried out with all power supplies turned off.

Otherwise electric shock may result.




: Be sure to ground the Converter. (Class D grounding)


4.1 Before wiring

- (1) Power voltage for the converter must conform to that for the detector to be connected.
- (2) Power supply wiring
 - Use 1.25sq 600V vinyl insulated cable (JISC3307) or equivalent as power supply cable.
- (3) Provide adequate protection of the dedicated cable (6 cores in total), which connects the detector to converter, using wire protection tube, etc. Separate these cables from the power cable (noise prevention).
- (4) Keep the wire for output signals as far as possible (more than 30cm) from the power line and heavy current lines to prevent induced noise. Also, wherever possible use a shielded cable and earth one point of the shield.

Note) For connection of wiring to the external terminals, use of solderless terminal with insulating sleeve is recommended. (for M3 screw)



4.2 Wiring to each terminal




COMMUNICATION TERMINAL (TM2) /INSERTION TERMINAL

	Terminal number			Remarks
	1	2	3	
RS232C	TXD	RXD	GND	Standard
RS485	TRX+	TRX-	GND	Option

Note 1) The heater power supply is the same as the converter power supply.

Note 2) Be sure to connect the shield of the cable to the ground in the main body.


4.3 Wiring and piping diagram



4.4 Handling of standard gas

(1) Handling

- 1) Make sure the handle is closed on the high pressure gas container, then detach the cap nut.
- 2) Attach the high pressure gas container using the cap nut with packing of the pressure reducing valve.
- 3) Make sure the secondary pressure adjusting valve is turned fully counterclockwise (pressure not applied) and the outlet needle is turned fully clockwise (closed), then open the handle.
- 4) Turn the secondary pressure adjusting valve clockwise and set to the normal value of 20 to 30 kPa, then open the outlet needle slowly to allow the gas to flow.



5. OPERATION

5.1 Preparation for operation

(1) Wiring check (Refer to “4.2”, “4.3”)



(2) Confirmation of the power supply specifications (Please check the main power supply and the power supply voltage specification of the detector.)



(3) Power ON.
Open the front flap. Turn “ON (-)” the power switch. (Refer to “2.2”)

OXYGEN ANALYZER
VER *.*.* YY/MM

The message shown left appears on the LCD screen.

WARM-UP
HEATER 234 °C

After about 6 seconds, the display is automatically switched to the warming-up screen.



(4) Warmup (After 10 minutes from power ON, accurate measurement data may be obtained.)



(5) Parameter setting, key operation outline
Move to each Menu with reference to the paragraph “5.2 Key operation flow diagram (outline), and set a necessary parameter. Refer to the paragraph “5.3 Initial parameter value table”.
If you need to change a parameter, refer to the “Chapter 8”.



(6) Calibration
At the first operation, perform manual calibration after warmup using a standard gas.
Refer to chapter 7 for calibration procedures.



(7) Auto calibration (option)
Automatic calibration may be performed at specified time intervals.
Refer to “8.2.2” for automatic calibration settings.





(8) Blowdown (option)
A flow guide tube blowdown function prevents the flow guide tube from clogging due to dust in the gas stream.
Refer to “8.3” for operation procedures.





Operation

5.2 Key operation flow diagram (outline)









5.3 Initial parameter value table

5.3.1 Parameters related to measurement

Parameter setting	Displayed message	Range	Initial value	Reference paragraph
Display range	OUTPUT RANGE RANGE1 RANGE2	Range1 or Range2	Range-1	8.1.1
Decimal point position (Range1) (Range2)	DECIMAL POINT 00.00	[00.00] [0.000]	[00.00]	8.1.2
Full scale (Range1) (Range2)	FULL SCALE 25.00	2 to 50 in 1 vol% steps	25.00 vol%	8.1.3
Calculation time of maximum and minimum values	CALCULATE TIME 024 h	0 to 240 hour in 1-hour steps	24 hour	8.1.4

5.3.2 Parameters related to calibration

Parameter setting	Displayed message	Range	Initial value	Reference paragraph
Auto calibration function (Displayed if the option is provided.)	AUTO CALIBRATION YES NO	YES or NO	Invalid (Auto calibration function: Invalid)	8.2.2
Date and time for starting automatic calibration (Displayed if the option is provided.)	START DATE 99/01/01 00:00	Date and time in the future in the calendar	99/01/01 00:00	8.2.2
Automatic calibration cycle time (Displayed if the option is provided.)	AUTO CAL. CYCLE 07d 00h	00d 00h to 99d23h (h: 00 to 23)	07d 00h	8.2.2
Calibration gas concentration-1 calibration gas concentration-2	SPAN ZERO 20.600% 02.000%	Span: 00.010 to 50.000 vol% Zero: 00.010 to 25.000 vol% in 0.001 vol% steps	Span: 20.600 vol% Zero: 02.000 vol%	8.1.7
Calibration wait time	CAL. WAIT TIME 030 s	10 to 300 sec. in 1 sec. steps	60 sec.	8.1.8
Calibration range setting	ABOUT CAL. RANGE BOTH CURRENT	Set calibration range Current or both range	BOTH	8.1.6

5.3.3 Parameters related to blowdown (displayed if the option is provided)

Parameter setting	Displayed message	Range	Initial value	Reference paragraph
Automatic blowdown function	BLOW DOWN YES <input checked="" type="checkbox"/> NO	YES or NO	NO (The automatic blowdown function is invalid.)	8.3.3
Date and time for starting automatic blowdown	START DATE 99/01/01 00:00	Date and time in the future in the calendar	99/01/01 00:00	8.3.3
Automatic blowdown cycle time	AUTO BLOW CYCLE 24h 00m	00h 00m to 99h 59m (m: 00 to 59)	24h 00m	8.3.3
Blowdown time	BLOW DOWN TIME 030 s	0 to 999 sec. in 1 sec. steps	30 sec.	8.3.3

5.3.4 Parameters related to maintenance

Parameter setting	Displayed message	Range	Initial value	Reference paragraph
Sensor check function for automatic calibration	SENSOR CHECK YES <input checked="" type="checkbox"/> NO	YES or NO	NO (Sensor check function for calibration is invalid.)	9.1.6
Sensor recovery function for automatic calibration	SENSOR RECOVER YES <input checked="" type="checkbox"/> NO	YES or NO	NO (Sensor recovery function for calibration is invalid.)	9.1.7

5.3.5 Other parameters

Parameter setting	Displayed message	Range	Initial value	Reference paragraph
Current date and time	DATE SET 00/00/01 00:00	Date and time in the calendar	(00/01/01 00:00)	9.2.1
Contact inputs 1 to 3	DI 1 NONE	DI1 to DI3 [NONE] [BLOW DOWN ON] [HEATER OFF] [PROHIBIT CAL.] [REMOTE CAL.] [REMOTE HOLD] [CALCULATE REST] [OUTPUT RANGE]	DI1 [NONE] DI2 [NONE] DI3 [NONE]	9.2.2
Alarm contact output	DO ALARM SET ALARM NONE	[ALARM NONE] [HIGH ALARM] [LOW ALARM] [H-HIGH ALARM] [L-LOW ALARM] [H/L ALARM] [HH/LL ALARM]	[ALARM NONE]	9.2.3
Upper limit of oxygen concentration (Range-1) (Range-2)	HIGH ALARM 50.000 vol%	0.001 to 55.000 vol% in 0.001 vol% steps	50.000 vol%	9.2.4
Lower limit of oxygen concentration (Range-1) (Range-2)	LOW ALARM 00.020 vol%	0.001 to 55.000 vol% in 0.001 vol% steps	00.020 vol%	9.2.5
Upper 2 limit of oxygen concentration (Range-1) (Range-2)	H-HIGH ALARM 55.000 vol%	0.001 to 55.000 vol% in 0.001 vol% steps	55.000 vol%	9.2.6
Lower 2 limit of oxygen concentration (Range-1) (Range-2)	L-LOW ALARM 00.010 vol%	0.001 to 55.000 vol% in 0.001 vol% steps	00.010 vol%	9.2.7
Hysteresis (Oxygen concentration alarm) (Range-1) (Range-2)	HYSTERESIS 10 %	0 to 20 % in 1 % steps	10 %	9.2.8
Analog output hold function (Maintenance hold) (Error hold)	OUTPUT HOLD YES NO	YES or NO	NO (Analog output hold function is invalid.)	9.2.9 9.2.13
Output value of analog output hold (Maintenance hold) (Error hold)	OUTPUT SELECT 0%	[0 %] (4 mA/0V) [100 %] (20 mA/1V) [Last output value] [Setting value]	[0 %](4 mA/0V)	9.2.10 9.2.14
Setting the value of analog output hold (Maintenance hold) (Error hold)	HOLD VALUE 00 %	0 to 100 % in 1 % steps	0 %	9.2.11 9.2.15

Parameter setting	Displayed message	Range	Initial value	Reference paragraph
Measurement recovery time	MEAS. WAIT TIME 010 s	0 to 300 sec. in 1 sec. steps	10 sec.	9.2.12
Key lock function	KEY LOCK YES NO	YES or NO	No (Key lock function is invalid.)	9.2.16
Adjustment of brightness	CONTRAST DOWN	(0 to 100 %)	50 %	9.2.17
Automatic OFF time	BACKLIGHT TIME 10 m	0 to 99 min. in 1 min. steps	10 min.	9.2.18

6. PERATION START AND SHUTDOWN

6.1 Starting

After correct wiring and piping has been completed, turn the power switch in the converter ON, and measuring operation will begin.

Note: 10 min. of warm-up time is necessary after power ON.

Caution of before starting

- (1) Furnace operation should only be started after 10 min. or more of warm-up time has elapsed.
- (2) When a detector is to be installed in a furnace already in operation, take care to blow out harmful gas from the furnace and then install the fully warmed up detector quickly.

6.2 Stopping operation

(1) When a process (furnace etc.) is to be shutdown for a short time i.e. a week or so

It is strongly recommended to keep the detector in operation to avoid possible deterioration of platinum electrodes in the detector and destruction of the wet sensor element (depending on the condition in furnace and/or ambient conditions) due to power ON-OFF.


In case of the detector with an ejector (option), shutdown the air source.

(2) When a process (furnace etc.) is to be shutdown for a long time


Turn OFF the power switch of the instrument after gas in the furnace has been replaced completely by ambient air.

6.3 Actions during operation

While the instrument is operating, the following displays can be changed.



6.4 Check the contents of display

The condition of the unit is displayed on the left of the LCD with three words. The maximum of three items are displayed on one display. If there are four or more items, “▼” is displayed at the bottom of the screen. Scroll the screen with the  key to display the fourth and subsequent items.

The unit displays the following three pieces of information:

- (1) Condition information (“6.4.1”), (2) Error information (“6.4.2”), (3) Alarm information (“6.4.3”)

6.4.1 Check of condition information

Display message	State	Remarks
WUP	Warm-up	Appears during warm-up
CAL	Auto calibration	Appears during auto calibration
S	Span calibration	Displayed together with “CAL” or “RIC” during span calibration.
Z	Zero calibration	Displayed together with “CAL” or “RIC” during zero calibration.
SCK	Sensor check	Displayed during sensor check.
SRC	Sensor recovery	Displayed during sensor recovery.
BLW	Automatic blowdown	Displayed during automatic blowdown.
RIC	Rich mode	Combustion efficiency option Displayed when electromotive force is 200mV but no more than 260mV
KYL	Key Lock	Displayed during key lock
RHO	Remote heater is off.	Displayed while remote heater is off.
RCP	Remote calibration is prohibited.	Displayed while remote calibration is prohibited.
RAH	Remote analog output hold	Displayed during remote analog output hold.
RCL	Remote calibration	Displayed during remote calibration.
RBL	Remote blowdown	Displayed during remote blowdown.

6.4.2 Checking the error information

Display message	Status	Remarks
Er1	Fault of heater temperature	Appears when control temperature of the heater exceeds the set range. The heater control is stopped.
Er2	Disconnection detection	Appears when disconnection is detected at the sensor, or thermocouples for temperature control or combustion control. The heater control is stopped.
Er3	Sensor error	Appears when the A/D value is saturated.
Er4	Span calibration error	Appears when the span calibration is abnormal. (The calibration gas is unstable. / The calibration factor setting is inappropriate.)
Er5	Zero calibration error	Appears when the zero calibration is abnormal. (The calibration gas is unstable. / The calibration factor setting is inappropriate.)

6.4.3 Checking the alarm information

Display message	Status	Remarks
ALM	Oxygen concentration error	Appears when the oxygen concentration exceeds any of specified HH / High / Lower / LL limit values. (Refer to “9.2.4” to “9.2.8”)
H	High limit error	Appears together with ALM.
L	Lower limit error	Appears together with ALM.
HH	HH limit error	Appears together with ALM.
LL	LL limit error	Appears together with ALM.

You can select one of the following seven alarms to output to the alarm contact (Numbers of contacts of the external terminal block: (21), (22)) when an oxygen concentration error occurs.

- (1) [Not used] : No alarm is output to the contact output.
- (2) [High limit alarm] : Alarm contact is output when an high limit alarm occurs.
- (3) [Lower limit alarm] : Alarm contact is output when a lower limit alarm occurs.
- (4) [HH limit alarm] : Alarm contact is output when an HH limit alarm occurs.
- (5) [LL limit alarm] : Alarm contact is output when a LL limit alarm occurs.
- (6) [High/lower limit alarm] : Alarm contact is output when an high or lower limit alarm occurs.
- (7) [HH / LL limit alarm] : Alarm contact is output when an HH or LL limit alarm occurs.

6.5 Oxygen detector standard output voltage

O ₂ concentration (%)	Output value (mV)	O ₂ concentration (%)	Output value (mV)	O ₂ concentration (%)	Output value (mV)
0.01	176.38	5.0	32.73	25.0	-4.475
0.1	123.15	10.0	16.71	30.0	-8.689
0.5	85.95	15.0	7.333	40.0	-15.34
1.0	69.93	20.0	0.683	50.0	-20.50
1.5	60.56	20.6	0	–	–
2.0	53.91	21.0	-0.445	–	–

7. CALIBRATION

In order to maintain good accuracy, proper calibration using calibration gas is necessary. The following 4 methods of calibration are provided.

- (1) Manual calibration (“8.2”), (2) Auto calibration (option) (“8.2.2”),
- (3) Remote calibration (“8.2.3”), (4) All calibration (option) (“8.2.4”)

7.1 Preparation

- Check of piping and wiring
Perform wiring and piping correctly referring to Item “4.3”. At this time, the main plug of standard gas should be left open. Since high pressure is present at piping connections, use blind-nut type joints and take special care with regard to air-tightness. Calibration gas flow should be 1.5 ± 0.5 L/min.
- Setting of calibration gas concentration
Referring to “8.1.7 Calibration gas setting” set the oxygen concentration in standard gas cylinder to be used.
- Setting of calibration range
Set the range for calibration according to “8.1.6 Operation setting screen of calibration range.”













8. SETTING AND OPERATING OF PARAMETER

8.1 Measured menu

8.1.1 Display range setting screen

Description

- You can set the display range of oxygen concentration value using this function.
- Settable range: Select one of the following
 - “Range 1”: Displayed in the range set in the range setting 1.
 - “Range 2”: Displayed in the range set in the range setting 2.

Procedure	Operation (example)	Setting the display range to “Range 1”	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key. The display range setting screen appears.	
(2)	 	Use the  key to select the range-1. Press the  key to set the value.	
(3)		Press the  key.	
(4)		When it is fixed, the display returns to the screen on the right.	
















Note

- If “Range setting” is set in the contact input setting, you cannot change the display range on this screen.

8.1.2 Decimal point position setting screen

Description

- You can set the decimal point position of full scale for oxygen concentration display using this function.
- Settable range: Select one of the following.
 - “00.00”: Displayed with two-digit integer and two decimal places.
 - “0.000”: Displayed with one-digit integer and three decimal places.

Procedure	Operation (example)	Setting the display of two-digit integer and two decimal places (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		Press the  key. The decimal point position setting screen appears.	
(3)	 	Use the  key to select the two-digit integer and two decimal places. Press the  key to set the value.	
(4)		Press the  key.	
(5)		When it is fixed, the display returns to the screen on the right.	




















Note

- If changing “0.000” to “00.00,” “25.00” is set as the full scale value.
- If changing “00.00” to “0.000,” “5.000” is set as the full scale value.

8.1.3 Full scale setting screen

Description















- You can set the full scale value for display of oxygen concentration value using this function.
- Settable range: If the decimal point position is set to “00.00”: 02.00 to 50.00 vol%
If the decimal point position is set to “0.000”: 2.000 to 9.000 vol%

Procedure	Operation (example)	Setting the full scale value to 20.00% (Range-1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Press the  key to display the screen on the right and press the  key. The full scale setting screen appears.	
(3)	  	Use the  and  key to set the full scale value. Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

8.1.4 Setting the screen for calculation time of maximum and minimum values

Description











- You can set the calculation time of maximum and minimum values of oxygen concentration value using this function.
- Settable range: 0 to 240h

Procedure	Operation (example)	Setting the calculation time of maximum and minimum values to 24 hours	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key. The screen for calculation time of maximum and minimum values setting screen appears.	
(2)	  	Use the  and  key to set the calculation time of maximum and minimum values. Press the  key to set the value.	
(3)		Press the  key.	
(4)		When it is fixed, the display returns to the screen on the right.	

8.1.5 Calibration error clear

Description













- You can clear the errors occurred during calibration using this function.
If an error occurs during calibration, an error display (Er4, Er5) and abnormal contact output (close) continues until the next calibration is properly completed.
- Clear the error display on the measurement screen and open the abnormal contact output.
- Error log information is not cleared.

Procedure	Operation (example)	Clearing a calibration error	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key. The calibration error clear appears.	
(2)		Press the  key. (The calibration error is not cleared yet.)	
(3)		Press the  key. (Calibration error cleared.)	
(4)		The display returns to the screen on the right.	

8.1.6 Operation setting screen of calibration range

Description

- During calibration, you can select single or common range for the calibration factor using this function.
- Settable range: Select one of the following.
 - (1) “Range interlock”: Performs calibration of the range that is currently displayed and sets the calibration factors of the other ranges to the same value as above.
 - (2) “Display range”: Performs calibration of the range that is currently displayed.

Procedure	Operation (example)	Setting the calibration range to range interlock	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key. The operation setting screen of calibration range appears.	
(2)	 	Use the  key to select the range interlock. Press the  key to set the value.	
(3)		Press the  key.	
(4)		When it is fixed, the display returns to the screen on the right.	

8.1.7 Calibration gas setting

Description

- Set calibration gas concentration (span/zero calibration gas concentrations).
Use the calibration gas concentration 1 for the range 1, and the calibration gas concentration 2 for the range 2.
- Use normal air (atmosphere) as a span calibration gas and set its concentration to 20.600% O₂/N₂.
- Settable range: Span calibration gas 00.010 to 50.000 %O₂/N₂
Zero calibration gas 00.010 to 25.000 %O₂/N₂

Procedure	Operation (example)	Setting the span/zero calibration gas concentrations (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)		The set content is displayed now.	
(3)	 	Use the and key to change the calibration gas concentrations. Press the key to set the value.	
(4)		The set content is displayed. Press the key.	
(5)		The display returns to the screen on the right.	













Note

- You cannot change the setting value during automatic calibration or remote calibration.
- Set with span calibration gas concentrations \geq zero calibration gas concentrations.

8.1.8 Calibration waiting setting (option)

Description

- Set the waiting time from supply of calibration gas to start of calibration.
(Set the time so that the calibration gas becomes stable before the calibration.)
- Settable range: 10 to 300sec.

Procedure	Operation (example)	Setting the waiting time to start of calibration to 20 seconds	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		The set content is displayed now. Use the  and  key to change the wait time. Press the  key to set the value.	
(3)		Press the  key.	
(4)		The display returns to the screen on the right.	

Caution


















- You cannot change the setting value during automatic calibration or remote calibration.



8.2 Manual calibration

8.2.1 Manual span/zero calibration


Description

- Span/zero is calibrated once by key operation.
- Calibration must be made in the order of span and zero.
- Perform calibration after a calibration gas is supplied to the detector and the output signal of the detector becomes stable.
- The operator shall perform open and close operations, or adjust the flow rate of calibration gas.
- During calibration, if the analog output hold function (maintenance hold) is enabled, the analog output signal is held at the set value. Even after the calibration, the hold is maintained during the set time as a measurement recovery time.

Procedure	Operation (example)	Executes span calibration and zero calibration.	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key, the manual span calibration screen appears. If supplying calibration gas manually (without the auto-calibration function) The operator shall open the span gas valve manually and adjust the flow rate to 1.5 ± 0.5 L/min.	
(2)		Press the  key to perform manual span calibration.	
(3)		Oxygen concentration value and cell electromotive force are displayed. Wait until the oxygen concentration is stabilized.	
(4)		Press the  key to determine the span calibration factor. During the process, the oxygen concentration value and cell electromotive force are highlighted.	
(5)		After the calibration is completed, the display returns to the screen on the right.	
(6)		If the operator opened the span gas valve manually, close the valve.	
(7)		Display the screen on the right in accordance with the key operation summary and press the  key, the manual zero calibration screen appears. If supplying calibration gas manually (without the auto-calibration function) The operator shall open the span gas valve manually and adjust the flow rate to 1.5 ± 0.5 L/min.	
(8)		Press the  key to perform manual zero calibration.	

(9)		Oxygen concentration value and cell electromotive force are displayed. Wait until the oxygen concentration is stabilized.	<div style="border: 1px solid black; padding: 2px;"> MANUAL ZERO CAL. 2.01 % 053.9 mV </div>
(10)		Press the  key to determine the zero calibration factor. During the process, the oxygen concentration value and cell electromotive force are highlighted.	<div style="border: 1px solid black; padding: 2px;"> MANUAL ZERO CAL. 2.01 % 053.9 mV </div>
(11)		After the calibration is completed, the display returns to the screen on the right.	<div style="border: 1px solid black; padding: 2px;"> CALIBRATION MENU MANUAL ZERO CAL. </div>
(12)		The operator shall close the zero gas valve manually.	


How to interrupt

- Press the  key to interrupt the operation.
- After the interruption, be sure to close the valves of span gas and zero gas.

































8.2.2 Auto calibration (option)

Description


- Calibration is performed at time intervals set in advance.
- Feed the standard gas for automatic calibration with span gas and zero gas by driving the solenoid valve which is connected to the calibration gas contact output (ZU/SV) on the terminal block. It is necessary to set “8.1.7 Calibration gas setting”.
- The word “CAL” is displayed on the left of the measurement screen during automatic calibration.
- If the output signal hold is set, the output signal is held to the set value during calibration.
- To perform sensor maintenance (sensor check, sensor recovery), “9.1.6 Sensor check setting for automatic calibration (option)” and “9.1.7 Sensor recovery setting for automatic calibration (option)” are required.
- Refer to Sections 4.2 and 4.3 for the wiring of solenoid valves.



Procedure	Operation (example)	Setting the automatic calibration so that it is performed every four days from 13:00, 08/02/25	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)		Press the key. The auto calibration valid/invalid setting screen appears.	
(3)	 	Use the key to select the auto calibration valid (YES). Press the key to set the value.	
(4)		Press the key to set the value.	
(5)		The screen on the right appears.	

(6)	 	<p>Press the  key to display the screen on the right and press the  key.</p> <p>The date and time for starting automatic calibration screen appears.</p>	
(7)	  	<p>Use the  and  key to set the auto calibration starting date and time screen. (Set the date and time of the future.)</p> <p>Press the  key to set the value.</p>	
(8)		<p>Press the  key.</p>	
(9)		<p>The screen on the right appears.</p>	
(10)	 	<p>Press the  key to display the screen on the right and press the  key.</p> <p>The cycle time setting of automatic calibration screen appears.</p>	
(11)	  	<p>Use the  and  key to set the auto calibration cycle time.</p> <p>Press the  key to set the value.</p>	
(12)		<p>Press the  key.</p>	
(13)		<p>The display returns to the screen on the right.</p>	

How to interrupt

- Press the  key to interrupt the operation.

Caution

Automatic calibration is not performed under the following conditions.


- Warming-up is being performed.
- Contact of “Prohibition of calibration” is being input.
- Contact of “Heater off” is being input.

8.2.3 Remote calibration

You can perform all calibration by the contact input of the external terminal block.

To perform remote calibration, install piping and wiring for the standard gas cylinder and the solenoid valve according to Section 4.

- (1) Set one of the contact inputs DI 1 to 3 to “Remote calibration” in accordance with the following operation procedure.
- (2) Close the contact set to the “Remote contact” for one second or more (depending on the settings of (17) to (19) and (20) of the terminal block).
- (3) Remote calibration is started. The word “RCL” is displayed on the left of the display panel, which disappears when the calibration is completed.










You can arbitrarily set the contact inputs (17), (18), (19) and (20) of the external terminal block (see “9.2.2 Contact input setting”).

Piping and wiring for the standard gas cylinder and the solenoid valve shall be installed.


Description

- You can perform all calibration by the contact input using this function.
- The solenoid valve is driven by contact signal from the terminal block to feed the standard gas for automatic calibration with span gas and zero gas.
- Refer to Sections 4.2 and 4.3 for the wiring of solenoid valves.

Procedure	Operation (example)	Executes remote calibration.	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key. The contact input setting screen appears.	
(2)	 	Press the key several times and select one of DI 1 to DI 3. Press the key.	
(3)		Press the key. Contact is set.	
(4)	 	Press the key several times and select “REMOTE CAL.”. Press the key to set the value.	

(5)		Press the  key.	
(6)		The screen on the right appears. Press the  key several times and return to the measurement screen.	
(7)		Close the contact set to the “REMOTE CAL.” Remote calibration is performed.	

How to interrupt

- Press the  key to interrupt the operation.

Caution

Automatic calibration is not performed under the following conditions.

- Warming-up is being performed.
- Contact of “Remote blow” is being input.
- Contact of “Prohibition of calibration” is being input.
- Contact of “Heater off” is being input.









8.2.4 All calibration (option)

Description


- Perform sensor maintenance [sensor check (setting), sensor recovery (setting)], span and zero calibration once for each sequentially by key operation.
- Feed the standard gas for automatic calibration with span gas and zero gas by driving the solenoid valve which is connected to the calibration gas contact output (ZU/SV) on the terminal block.
- If the output signal hold is set, the output signal is held to the set value during calibration. After the calibration, the hold is maintained until the time set in the measurement waiting time elapses.
- To perform sensor maintenance (sensor check, sensor recovery), “9.1.6 Sensor check setting for automatic calibration (option)” and “9.1.7 Sensor recovery setting for automatic calibration (option)” are required.

Note that the sensor recovery is performed if it is determined to be required at the sensor check.

- Refer to Sections 4.2 and 4.3 for the wiring of solenoid valves.

Procedure	Operation (example)	Executes all calibration.	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key, the all calibration performing screen appears.	
(2)		Press the  key to perform all calibration.	
(3)		The value of the concentration of oxygen and the cell electromotive force are displayed while executing the all calibration.	
(4)		After the all calibration is completed, the display returns to the screen on the right.	

How to interrupt

- Press the  key to interrupt the operation.

8.3 BLOWDOWN (OPTION)

In order to prevent the flow guide tube from being clogged with dust contained in gas being measured, dust deposits in the flow guide tube is removed by blowing compressed air such as instrumentation air, etc. Use the blowdown function by one of the following three methods.

- (1) Manual blowdown (“8.3.2”), (2) Automatic blowdown (“8.3.3”),
(3) Remote blowdown (“8.3.4”)









8.3.1 Preparation for blowdown

- Wiring/piping check
Perform wiring and piping correctly referring to Item. 4.3. Since high pressure is applied to the piping, be sure to use blind-nut type joints at connections. Special care should be taken with regard to air-tightness.
- Setting of blowdown time
Referring to “8.3.3 Automatic blowdown”, set blowdown time.


8.3.2 Manual blowdown

Description

- You can perform blowdown operation once by key operation using this function.

Procedure	Operation (example)	Performing manual blowdown	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key, the manual blowdown performing screen enters.	
(2)		Press the  key to perform manual blowdown.	
(3)		While executing the screen on the right appears.	
(4)		After the calibration is completed, the display returns to the screen on the right.	


How to interrupt

- Press the  key to interrupt the operation.

































8.3.3 Automatic blowdown

Description


- Blowdown operation is performed at time intervals set in advance.
- Remove dust by blowing instrumentation air, etc. into the flow guide tube with blowdown nozzle by driving the solenoid valve which is connected to the blow contact output (BLOW) on the terminal block .
- The word “BLW” is displayed on the left of the measurement screen during automatic blowdown.
- When output signal is set in hold mode during blowdown operation, it is held at a value prior to the start of blowdown operation. The holding time is extended to the time designated for the next measurement even after the blowdown operation of end.



Procedure	Operation (example)	Setting the blowdown so that it is performed for 30 seconds every 24 hours from 13:00, 08/02/25	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)		Press the key. The auto blowdown valid/invalid setting screen appears.	
(3)	 	Use the key to select the auto blowdown valid (YES). Press the key to set the value.	
(4)		Press the key.	
(5)		The screen on the right appears.	
(6)	 	Press the key to display the screen on the right and press the key. The date and time setting of automatic blowdown screen appears.	

(7)	  	<p>Use the  and  key to set the auto blowdown starting date and time. (Set the date and time of the future.) Press the  key to set the value.</p>	<div style="border: 1px solid black; padding: 2px;"> START DATE 08/02/25 13:00 </div>
(8)		<p>Press the  key.</p>	<div style="border: 1px solid black; padding: 2px;"> START DATE 08/02/25 13:00 </div>
(9)		<p>The screen on the right appears.</p>	<div style="border: 1px solid black; padding: 2px;"> SET AUTO BLOW START DATE </div>
(10)	 	<p>Press the  key to display the screen on the right and press the  key. The auto setting blowdown interval screen appears.</p>	<div style="border: 1px solid black; padding: 2px;"> SET AUTO BLOW AUTO BLOW CYCLE </div>
(11)	  	<p>Use the  and  key to set the auto blowdown interval. Press the  key to set the value.</p>	<div style="border: 1px solid black; padding: 2px;"> AUTO BLOW CYCLE 24h 00m </div>
(12)		<p>Press the  key.</p>	<div style="border: 1px solid black; padding: 2px;"> AUTO BLOW CYCLE 24h 00m </div>
(13)		<p>The screen on the right appears.</p>	<div style="border: 1px solid black; padding: 2px;"> SET AUTO BLOW AUTO BLOW CYCLE </div>
(14)	 	<p>Press the  key to display the screen on the right and press the  key. The setting blowdown time screen appears.</p>	<div style="border: 1px solid black; padding: 2px;"> SET AUTO BLOW BLOW DOWN TIME </div>
(15)	  	<p>Use the  and  key to set the blowdown time. (Common with the manual blowdown.) Press the  key to set the value.</p>	<div style="border: 1px solid black; padding: 2px;"> BLOW DOWN TIME 030 S </div>
(16)		<p>Press the  key.</p>	<div style="border: 1px solid black; padding: 2px;"> BLOW DOWN TIME 030 S </div>
(17)		<p>The display returns to the screen on the right.</p>	<div style="border: 1px solid black; padding: 2px;"> SET AUTO BLOW BLOW DOWN TIME </div>

How to interrupt


- Press the  key to interrupt the operation.

8.3.4 Remote blowdown

You can perform blowdown by the contact input of the external terminal block.

To perform remote blowdown, install piping and wiring for the supply air and the solenoid valve according to Section 4.

- (1) Set one of the contact inputs DI 1 to 3 to “Blowdown ON” in accordance with the following operation procedure.
- (2) Close the contact set to the “Blowdown ON” for one second or more (depending on the settings of (17) to (19) and (20) of the terminal block).
- (3) Blowdown is started. The word “RBL” is displayed on the left of the display panel, which disappears when the blowdown is completed.










You can arbitrarily set the contact inputs (17) to (19) and (20) of the terminal block (see “9.2.2 Contact input setting”).

Piping and wiring for the supply air and the solenoid valve shall be installed.


Description

- You can perform blowdown by the contact input using this function.
- Feed the supply air for automatic blowdown by driving the solenoid valve which is connected to the blow contact output (BLOW) on the terminal block.
- Refer to Sections 4.2 and 4.3 for the wiring of solenoid valves.

Procedure	Operation (example)	Performing remote blowdown	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key. The contact input setting screen appears.	
(2)	 	Press the key several times and select one of DI 1 to DI 3. Press the key.	
(3)		Press the key. Contact is set.	
(4)	 	Press the key several times and select “BLOW DOWN ON”. Press the key to set the value.	

(5)		Press the  key.	
(6)		The screen on the right appears. Press the  key several times and return to the measurement screen.	
(7)		Close the contact set to the “Blowdown ON.” Blowdown is performed.	


How to interrupt



















- Press the  key to interrupt the operation.

9. Maintenance menu

9.1 Error log display

Description

- You can display an error log on the screen using this function.
- A latest piece of error information is displayed first.
The maximum of 12 pieces of error information are saved.
Press the  key to display the older pieces of error information.
The latest piece of error information is displayed next to the oldest piece of error information.
- The oldest piece of error information is overwritten by a new one.

Procedure	Operation (example)	Displaying an error log on the screen	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		Use the  key to select the error log screen.	
(3)		Press the  key, the latest error log appears.	
(4)		Press the  key to display the previous piece of error log information.	
(5)		Press the  key, the display returns to the screen on the right.	
(6)		Press the  key again to return to the screen on the right.	











Error history

Display message	Status
Sensorline Error	Sensor line disconnection of the zirconia oxygen analyzer was detected.
TC-line Error	Temperature control line disconnection of the zirconia oxygen analyzer was detected.
Sub temp. Error	Line disconnection of the thermocouple for combustion control was detected.
Warm-up Error	Warming-up was not completed within the warming-up monitoring time (45 minutes). <ul style="list-style-type: none"> Warming-up is properly completed if the heater temperature of the zirconia oxygen analyzer becomes the control temperature (800°C) ± 1°C and stable for one minute.
Cell temp. Error	Heater temperature exceeds the specified range (800°C ± 70°C)
Span gas Error	<ul style="list-style-type: none"> The concentration of the calibration span gas being supplied is not stable. (In a discrimination treatment of stability, the error of ± 0.2% or more compared to the value in the previous treatment continues.)
Zero gas Error	<ul style="list-style-type: none"> The concentration of the calibration zero gas being supplied is not stable. (In a discrimination treatment of stability, the error of ± 0.2% or more compared to the value in the previous treatment continues.)
Span cal. Error	Span calibration failed. (Calibration factor could not be determined.)
Zero cal. Error	Zero calibration failed. (Calibration factor could not be determined.)
Sensor Error	An error was detected in the A/D conversion of oxygen concentration value of the zirconia oxygen analyzer. (260 mV or more, -50 mV or less)
A/D data Error	An error was detected in the A/D conversion of oxygen concentration value of the zirconia oxygen analyzer. (260 mV or more, -50 mV or less)

9.1.1 Clearing error logs


Description













- You can clear all error logs saved using this function.

Procedure	Operation (example)	Clearing all error logs saved	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 2px;"> MAINTÉ MENU ERROR LOG </div>
(2)		Use the  key to select the error log clear screen.	<div style="border: 1px solid black; padding: 2px;"> ERROR LOG DISP CLEAR </div>
(3)		Press the  key to clearing error logs. (However, it has not been deleted yet.)	<div style="border: 1px solid black; padding: 2px;"> CLEAR ERROR LOG YES </div>
(4)		The screen is displayed again to check. Press the  key to clear all the error logs.	<div style="border: 1px solid black; padding: 2px;"> CLEAR ERROR LOG YES? </div>
(5)		After the processing is completed, the display changes to the menu screen.	<div style="border: 1px solid black; padding: 2px;"> ERROR LOG DISP CLEAR </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 2px;"> MAINTÉ MENU ERROR LOG </div>

9.1.2 Alarm log display

Description

- You can display alarm logs on the screen using this function.
- A latest piece of alarm information is displayed first.
The maximum of 12 pieces of alarm information are saved.
Press the  key to display the older pieces of alarm information.
The latest piece of alarm information is displayed next to the oldest piece of alarm information.
- The oldest piece of alarm information is overwritten by a new one.

Procedure	Operation (example)	Displaying alarm logs on the screen	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 5px;"> MAINTENANCE MENU ALARM LOG </div>
(2)		Use the  key to select the alarm log display screen.	<div style="border: 1px solid black; padding: 5px;"> ALARM LOG DISP CLEAR </div>
(3)		Press the  key, the latest alarm log appears.	<div style="border: 1px solid black; padding: 5px;"> YY/MM/DD HH:MM ***** </div>
(4)		Press the  key to display the previous piece of alarm log information.	<div style="border: 1px solid black; padding: 5px;"> YY/MM/DD HH:MM ***** </div>
(5)		Press the  key, the display returns to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> ALARM LOG DISP CLEAR </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> MAINTENANCE MENU ALARM LOG </div>











Alarm log

Display message	Status
High alarm	Oxygen concentration value exceeded a specified upper limit.
Low alarm	Oxygen concentration value exceeded a specified lower limit.
Hi-High alarm	Oxygen concentration value exceeded a specified upper 2 limit.
Low-Low alarm	Oxygen concentration value exceeded a specified lower 2 limit.

9.1.3 Clearing alarm logs


Description













- You can clear all alarm logs using this function.

Procedure	Operation (example)	Clearing all alarm logs saved	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 5px;"> MAINTÉ MENU ALARM LOG </div>
(2)		Use the  key to select the alarm log clear screen.	<div style="border: 1px solid black; padding: 5px;"> ALARM LOG DISP CLEAR </div>
(3)		Press the  key to perform clearing alarm logs. (However, it has not been deleted yet.)	<div style="border: 1px solid black; padding: 5px;"> CLEAR ALARM LOG YES </div>
(4)		The screen is displayed again to check. Press the  key to clear all the alarm logs.	<div style="border: 1px solid black; padding: 5px;"> CLEAR ALARM LOG YES? </div>
(5)		After the processing is completed, the display changes to the menu screen.	<div style="border: 1px solid black; padding: 5px;"> ALARM LOG DISP CLEAR </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> MAINTÉ MENU ALARM LOG </div>

9.1.4 Operation log display

Description

- You can display operation logs on the screen using this function.
- A latest piece of operation information is displayed first.
The maximum of 12 pieces of operation information are saved.
Press the  key to display the older pieces of operation information.
The latest piece of operation information is displayed next to the oldest piece of operation information.
- The oldest piece of operation information is overwritten by a new one.

Procedure	Operation (example)	Displaying operation logs on the screen	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 5px;"> MAINTENANCE MENU OPERATION LOG </div>
(2)		Use the  key to select the operation log display screen.	<div style="border: 1px solid black; padding: 5px;"> OPERATION LOG DISP CLEAR </div>
(3)		Press the  key, the latest operation log appears.	<div style="border: 1px solid black; padding: 5px;"> YY/MM/DD HH:MM ***** </div>
(4)		Press the  key to display the previous piece of operation log information.	<div style="border: 1px solid black; padding: 5px;"> YY/MM/DD HH:MM ***** </div>
(5)		Press the  key, the display returns to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> OPERATION LOG DISP CLEAR </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> MAINTENANCE MENU OPERATION LOG </div>











Operation log

Display message	Status
Auto cal.	Automatic calibration was performed.
All calibration	All calibration was performed.
Manual span cal.	Manual span calibration was performed.
Manual zero cal.	Manual zero calibration was performed.
M sensor check	Manual sensor check was performed.
M sensor recover	Manual sensor recovery was performed.
Auto blow down	Automatic blowdown was performed.
Manual blow down	Manual blowdown was performed.
Prohibit cal.	Calibration was prohibited by contact input.
Heater off	Heater was turned off by contact input.
Cancel Auto cal.	Automatic calibration was forcibly canceled.
Cancel all cal.	All calibration was forcibly canceled.
Cancel span cal.	Manual span calibration was forcibly canceled.
Cancel zero cal.	Manual zero calibration was forcibly canceled.
Cancel zr-check	Manual sensor check was forcibly canceled.
Cancel zr-recover	Manual sensor recovery was forcibly canceled.
Cancel A-blow	Automatic blowdown was forcibly canceled.
Cancel M-blow	Manual blowdown was forcibly canceled.
Remote blow down	Blowdown was performed by contact input.
Remote cal.	Calibration was performed by contact input.
Remote Aout hold	Analog output hold was performed by contact input.
Remote reset	Calculations of maximum and minimum of oxygen concentration values were reset by contact input.
Cancel R-cal.	Remote calibration was forcibly canceled.

9.1.5 Clearing operation logs

Description













- You can clear all operation logs saved using this function.

Procedure	Operation (example)	Clearing all operation logs saved	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 2px;"> MAINTENANCE MENU OPERATION LOG </div>
(2)		Use the  key to select the operation log clear screen.	<div style="border: 1px solid black; padding: 2px;"> OPERATION LOG DISP CLEAR </div>
(3)		Press the  key to perform clearing operation logs. (However, it has not been deleted yet.)	<div style="border: 1px solid black; padding: 2px;"> CLEAR OPERAT. LOG YES </div>
(4)		The screen is displayed again to check. Press the  key to clear all the operation logs.	<div style="border: 1px solid black; padding: 2px;"> CLEAR OPERAT. LOG YES? </div>
(5)		After the processing is completed, the display changes to the menu screen.	<div style="border: 1px solid black; padding: 2px;"> OPERATION LOG DISP CLEAR </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 2px;"> MAINTENANCE MENU OPERATION LOG </div>

9.1.6 Sensor check setting for automatic calibration (option)

Description











- You can set if a sensor check is performed for calibration using this function.

Procedure	Operation (example)	Performing setting so that a sensor check is performed for calibration	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 2px;"> MAINTE MENU CAL. CELL MAINTE </div>
(2)		Press the  key. The sensor check setting for calibration screen appears.	<div style="border: 1px solid black; padding: 2px;"> CAL. CELL MAINTE SENSOR CHECK </div>
(3)	 	Use the  key to select the sensor check valid (YES). Press the  key to set the value.	<div style="border: 1px solid black; padding: 2px;"> SENSOR CHECK YES NO </div>
(4)		Press the  key.	<div style="border: 1px solid black; padding: 2px;"> SENSOR CHECK YES </div>
(5)		The display returns to the screen on the right.	<div style="border: 1px solid black; padding: 2px;"> CAL. CELL MAINTE SENSOR CHECK </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 2px;"> MAINTE MENU CAL. CELL MAINTE </div>

9.1.7 Sensor recovery setting for automatic calibration (option)

Description












- You can set if a sensor recovery is performed for calibration using this function.
Note that the sensor recovery is performed only if it is determined to be required at the sensor check.
- This function is performed only if valid is selected in the sensor check setting for calibration.

Procedure	Operation (example)	Performing setting so that sensor recovery is performed for calibration	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 5px;"> MAINTE MENU CAL. CELL MAINTE </div>
(2)		Use the  key to select the sensor recovery setting screen for calibration.	<div style="border: 1px solid black; padding: 5px;"> CAL. CELL MAINTE SENSOR RECOVER </div>
(3)		Use the  key to select the sensor recovery valid (YES).	<div style="border: 1px solid black; padding: 5px;"> SENSOR RECOVER YES NO </div>
(4)		Press the  key to set the value.	<div style="border: 1px solid black; padding: 5px;"> SENSOR RECOVER YES </div>
(5)		After the setting is completed, the display returns to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> CAL. CELL MAINTE SENSOR RECOVER </div>
(6)		Press the  key again to return to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> MAINTE MENU CAL. CELL MAINTE </div>


9.1.8 Performing a manual sensor check

Description

- Supply zero calibration gas to the detector in order to calculate the internal impedance R of the sensor.
- If the internal impedance R is more than 100 Ω, perform a reset operation of the sensor.

Procedure	Operation (example)	Performing a sensor check on the screen	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key, the manual sensor check performing screen appears.	
(2)		Press the  key to perform manual sensor check. If supplying calibration gas manually (without the auto-calibration function) The operator shall open the zero gas valve manually and adjust the flow rate to 1.5 ± 0.5 L/min. If your detector has the auto-calibration function, you can activate the external solenoid valve using the contact output signal at the terminal block.	
(3)		Oxygen concentration value and cell electromotive force are displayed. Wait until the oxygen concentration is stabilized.	
(4)		Press the  key to perform sensor check process. During the process, the sensor impedance is displayed.	
(5)		After the calibration is completed, the display returns to the screen on the right.	
(6)		If the operator opened the zero gas valve manually, close the valve.	







How to interrupt

- Press the  key to interrupt the operation.
- After the interruption, be sure to close the valves of zero gas.


9.1.9 Performing manual sensor recovery

Description

- Apply an alternating current to the sensor if the internal impedance $R > 100 \Omega$ in a sensor diagnosis. If $R \leq 100 \Omega$, this process cannot be performed.

Procedure	Operation (example)	Performing sensor recovery on the screen	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key, the manual sensor recovery performing screen appears.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> MAINTENANCE MENU SENSOR RECOVER </div>
(2)		Press the  key to perform manual sensor recovery. If supplying calibration gas manually (without the auto-calibration function) The operator shall open the span gas valve manually and adjust the flow rate to 1.5 ± 0.5 L/min.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> SENSOR RECOVER START </div>
(3)		If your detector has the auto-calibration function, you can activate the external solenoid valve using the contact output signal at the terminal block. Oxygen concentration value and cell electromotive force are displayed. Wait until the oxygen concentration is stabilized.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> SENSOR RECOVER 2.01 % 053.9 mV </div>
(4)		Press the  key to determine the span calibration factor. During the process, the treating method is displayed.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> SENSOR RECOVER AC </div>
(5)		After the calibration is completed, the display returns to the screen on the right.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> SENSOR RECOVER START </div>
(6)		If the operator opened the span gas valve manually, close the valve.	





How to interrupt

- Press the  key to interrupt the operation.
- After the interruption, be sure to close the valves of zero gas.

9.1.10 Cell internal resistance display

Description













- You can display the latest cell internal resistance of the zirconia oxygen analyzer in a sensor check, using this function.

Procedure	Operation (example)	Displaying an internal resistance of the zirconia oxygen analyzer	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	<div style="border: 1px solid black; padding: 5px;"> MAINTE MENU CELL RESISTOR </div>
(2)		Press the  key.	<div style="border: 1px solid black; padding: 5px;"> CELL RESISTOR 50 Ω </div>
(3)		The display returns to the screen on the right.	<div style="border: 1px solid black; padding: 5px;"> MAINTE MENU CELL RESISTOR </div>

9.1.11 Maintenance mode setting

Description

- You can set the maintenance mode to valid or invalid with this function.
- If the maintenance mode is set to valid, the analog output signal is held at the set value (see “9.2.10 Hold value setting.”) and the contact output for maintenance of the external contact is on. The data portion of the measurement screen flickers.

Procedure	Operation (example)	Setting the current date and time to 13:00, 08/02/25	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key, the maintenance mode setting screen appears.	
(2)	 	Use the  key to select the maintenance mode valid (YES). Press the  key to set the value.	
(3)		Press the  key.	
(4)		The display returns to the screen on the right.	

Note















- If an error occurs while the maintenance mode is enabled, error handling is prioritized.
- If the analog output hold function (error hold) is enabled, the analog output signal is held at the value set at the hold value setting (error hold).
- The data portion of the measurement screen flickers and is highlighted.

9.2 Parameter menu

9.2.1 Current date and time setting

Description

- You can set a current date and time for the unit using this function.
- Settable range: date and time in the future in the calendar

Procedure	Operation (example)	Setting the current date and time to 13:00, 08/02/25	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	  	Use the  and  key to set the date and time. Press the  key to set the value.	
(3)		Press the  key.	
(4)		The display returns to the screen on the right.	

9.2.2 Contact input setting

Description

- You can set the functions for the contact inputs 1 to 3 using this function.
- Settable range: Select one of the following
 - (1) [NONE] : Performs no treatment by contact input.
 - (2) [BLOW DOWN ON] : Performs blowdown by contact input.
(Switch OFF to ON to perform blowdown.)
 - (3) [HEATER OFF] : Turn off the heater by contact input.
(OFF/ON: Heater ON/Heater OFF)
 - (4) [PROHIBIT CAL.] : Sets if calibration is prohibited or valid by contact input.
(OFF/ON: Calibration is valid/prohibited.)
 - (5) [REMOTE CAL.] : Performs all calibration by contact input.
(Switch OFF to ON to perform calibration.)
 - (6) [REMOTE HOLD] : Holds the AO by contact input.
(OFF/ON: not held/held)
 - (7) [CALCULATE REST] : Resets maximum and minimum calculations of O₂ by contact input.
(Switch OFF to ON to perform calibration.)
 - (8) [OUTPUT RANGE] : Switches the range by contact input.
(OFF/ON: Range-1/Range-2)














Note) The functions other than “NONE” cannot be set for multiple contacts.

Procedure	Operation (example)	Setting the blowdown function for the contact input 1	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)	 	Use the key to select the contact input 1 setting screen. Press the key to set the value. (Also follow this procedure for the contact inputs 2 and 3.)	
(3)		Use the key to select the function for contact input 1.	
(4)		The item selected is highlighted. Press the key to set the value.	
(5)		Press the key.	
(6)		The display returns to the screen on the right.	

9.2.3 Selection of alarm contact output

Description

- You can set the alarm conditions for alarm contact output using this function.
- Settable range: Select one of the following.
 - (1) [ALARM NONE] : Alarm contact output is not performed.
 - (2) [HIGH ALARM] : Alarm contact output is performed when an high limit alarm occurs.
 - (3) [LOW ALARM] : Alarm contact output is performed when an lower limit alarm occurs.
 - (4) [HH ALARM] : Alarm contact output is performed when an HH limit alarm occurs.
 - (5) [LL ALARM] : Alarm contact output is performed when an LL limit alarm occurs.
 - (6) [H/L ALARM] : Alarm contact output is performed when an high or lower limit alarm occurs.
 - (7) [HH/LL ALARM] : Alarm contact output is performed when an HH or LL limit alarm occurs.

Procedure	Operation (example)	Setting the lower limit alarm function for alarm contact output	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		The selection of alarm contact output setting screen appears.	
(3)	 	Use the  key to select the low alarm. Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

9.2.4 High limit setting of oxygen concentration

Description

- You can set the high limit of oxygen concentration using this function.
Use the oxygen concentration 1 for the range 1, and the oxygen concentration alarm 2 for the range 2.
- Settable range: 0.001 to 55.000 vol%

Procedure	Operation (example)	Setting the high limit of oxygen concentration to “50.000 vol%” (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)	 	Use the key to select the oxygen concentration high limit value setting screen. Press the key to set the value.	
(3)	 	Use the and key to set the oxygen concentration upper limit value. Press the key to set the value.	
(4)		Press the key.	
(5)		Press the key.	
(6)		The display returns to the screen on the right.	

Note

- A setting error occurs if the following condition is not satisfied:
“HH limit of oxygen concentration” \geq “high limit of oxygen concentration” \geq “Lower limit of oxygen concentration” \geq “LL limit of oxygen concentration”

9.2.5 Lower limit setting of oxygen concentration

Description

- You can set the lower limit of oxygen concentration using this function.
Use the oxygen concentration 1 for the range 1, and the oxygen concentration alarm 2 for the range 2.
- Settable range: 0.001 to 55.000 vol%

Procedure	Operation (example)	Setting the lower limit of oxygen concentration to “00.020 vol%” (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)	 	Use the key to select the oxygen concentration lower limit value setting screen. Press the key to set the value.	
(3)	 	Use the and key to set the oxygen concentration lower limit value. Press the key to set the value.	
(4)		Press the key.	
(5)		Press the key.	
(6)		The display returns to the screen on the right.	

Note

- A setting error occurs if the following condition is not satisfied:
“HH limit of oxygen concentration” \geq “high limit of oxygen concentration” \geq “Lower limit of oxygen concentration” \geq “LL limit of oxygen concentration”

9.2.6 HH limit setting of oxygen concentration

Description

- You can set the HH limit of oxygen concentration using this function.
Use the oxygen concentration 1 for the range 1, and the oxygen concentration alarm 2 for the range 2.
- Settable range: 0.001 to 55.000 vol%

Procedure	Operation (example)	Setting the HH limit of oxygen concentration to “55.000 vol%” (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the key.	
(2)	 	Use the key to select the oxygen concentration HH limit value setting screen. Press the key to set the value.	
(3)	 	Use the and key to set the oxygen concentration HH limit value. Press the key to set the value.	
(4)		Press the key.	
(5)		Press the key.	
(6)		The display returns to the screen on the right.	























Note

- A setting error occurs if the following condition is not satisfied:
“HH limit of oxygen concentration” \geq “High limit of oxygen concentration” \geq “Lower limit of oxygen concentration” \geq “LL2 limit of oxygen concentration”

9.2.7 LL limit setting of oxygen concentration

Description

- You can set the LL limit of oxygen concentration using this function.
Use the oxygen concentration 1 for the range 1, and the oxygen concentration alarm 2 for the range 2.
- Settable range: 0.001 to 55.000 vol%

Procedure	Operation (example)	Setting the lower 2 limit of oxygen concentration to “00.010 vol%” (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Use the  key to select the oxygen concentration LL limit value setting screen. Press the  key to set the value.	
(3)	  	Use the  and  key to set the oxygen concentration LL limit value. Press the  key to set the value.	
(4)		Press the  key.	
(5)		Press the  key.	
(6)		The display returns to the screen on the right.	























Note

- A setting error occurs if the following condition is not satisfied:
“HH limit of oxygen concentration” \geq “High limit of oxygen concentration” \geq “Lower limit of oxygen concentration” \geq “LL limit of oxygen concentration”

9.2.8 Hysteresis Setting

Description

- You can set the hysteresis for alarm condition of oxygen concentration.
Use the oxygen concentration 1 for the range 1, and the oxygen concentration alarm 2 for the range 2.
Perform the setting using the percentage (%) of the range compared to the full scale.
- Settable range: 0 to 20 %


Procedure	Operation (example)	Setting the hysteresis for alarm condition of oxygen concentration to “20%” (Range 1)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Use the  key to select the hysteresis setting screen. Press the  key to set the value.	
(3)	  	Use the  and  key to set the hysteresis. Press the  key to set the value.	
(4)		Press the  key.	
(5)		Press the  key.	
(6)		The display returns to the screen on the right.	

Hysteresis:

If the value fluctuates around the condition value, there is a possibility that alarms occur frequently. When determining alarms, set a hysteresis width for the condition in order to prevent chattering.

For alarm check, set the percentage (%) of the range compared to the full scale as hysteresis width (see the figure below).
















This is common among “HH limit value,” “High limit value,” “Lower limit value,” and “LL limit value.”



9.2.9 Hold treatment setting (maintenance hold)

Description

- You can set if the analog output hold function is valid or invalid using this function.
- If the analog output hold function is valid, the value set for the analog output (see “9.2.10 Hold value setting (maintenance hold)”) is held at the value set for analog output when the following treatment is performed.
 - Calibration (Auto, All, Manual, Remote)
 - Blowdown (Auto, Manual, Remote)
 - Sensor diagnosis, Sensor recoverable, PID auto tuning
 - While the maintenance mode is set to “Valid.”

Procedure	Operation (example)	Setting the analog output hold function to valid	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		Press the  key. The analog output hold setting screen appears.	
(3)	 	Use the  key to select the output hold valid (YES). Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	


















Note

- If an error occurs while the analog output hold function (error hold) is set to “Valid,” error hold processing is prioritized.
- Analog output signal during warming up is held at 0% (4 mA/0 V).

9.2.10 Hold value setting (maintenance hold)

Description




















- Using this function, you can set (select) the output value of analog output signal when the analog output hold function (maintenance hold) is enabled.
- If the maintenance mode is set to “Valid,” analog output signal is held at the value set in this procedure.
- Settable range: Select one of the following.
 - (1) [0%] : Held at 0% (4 mA/0 V)..
 - (2) [100%] : Held at 100% (20 mA/1 V).
 - (3) [Last value] : Held at the value immediately before the value for analog hold.
 - (4) [Setting value] : Held at the value set as the “9.2.11 Setting of hold setting value (maintenance hold)”.

Procedure	Operation (example)	Setting the output value of analog output hold to “0%”	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Press the  key to display the screen on the right and press the  key. The analog output hold value setting screen appears.	
(3)	 	Use the  key to select the hold value. Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

9.2.11 Setting of hold setting value (maintenance hold)

Description




















- Using this function, you can set the output value of analog output signal to an arbitrary value when the analog output hold function (maintenance hold) is enabled.
- This function is enabled if “Setting value” is set at “9.2.10 Hold value setting (maintenance hold).”
- Set the output value of analog output signal as a percentage (%) of the full-scale value of the display range. 0% is equivalent to 0 vol% (4 mA/0 V) and 100 % is to the full-scale value (20 mA/1 V).
- Settable range: 0 to 100 %

Procedure	Operation (example)	Setting the output value of analog output hold to “000%”	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Press the  key to display the screen on the right and press the  key. The hold setting value setting screen appears.	
(3)	  	Use the  and  key to set the hold value. Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

9.2.12 Setting of measurement recovery time (maintenance hold)

Description
















- Using this function, you can set the time between hold condition (such as a calibration processing) and returning to the measurement condition (extension of hold) when the analog output hold function (maintenance hold) is enabled.
- Settable range: 0 to 300 sec.

Procedure	Operation (example)	Setting the time for extension of hold to “10 seconds”	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Press the  key to display the screen on the right and press the  key. The measurement recovery time setting screen appears.	
(3)	  	Use the  and  key to set the measurement recovery time. Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

9.2.13 Hold treatment setting (error hold)

Description

- Using this function, you can set whether the analog output hold function is valid or invalid when an error occurs.
- If the analog output hold function (error hold) is set to valid, analog output signal is held at the set value (see “9.2.14 Hold value setting (error hold)”) if an error occurs.

Procedure	Operation (example)	Setting the analog output hold function to valid	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		Press the  key. The analog output hold setting screen appears.	
(3)	 	Use the  key to select the output hold valid (YES). Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

Note

- If an error occurs while the analog output hold function (error hold) is set to “Valid,” error hold processing is prioritized.
- Analog output signal during warming up is held at 0% (4 mA/0 V).

9.2.14 Hold value setting (error hold)

Description




















- Using this function, you can set (select) the output value of analog output signal when the analog output hold function (error hold) is enabled.
- If the maintenance mode is set to “Valid,” analog output signal is held at the value set in this procedure.
- Settable range: Select one of the following.
 - (1) [0%] : Held at 0% (4 mA/0 V).
 - (2) [100%] : Held at 100% (20 mA/1 V).
 - (3) [Last value] : Held at the value immediately before the value for analog hold.
 - (4) [Setting value] : Held at the value set as the “9.2.15 Setting of hold setting value (error hold)”.

Procedure	Operation (example)	Setting the output value of analog output hold to “0%”	
	Key operation	Description	Displayed message (LCD)
(1)	ENTER	Display the screen on the right in accordance with the key operation summary and press the ENTER key.	<div style="border: 1px solid black; padding: 2px;">PARAMETER MENU</div> <div style="border: 1px solid black; padding: 2px;">AO HOLD (ERROR)</div>
(2)	▲ ENTER	Press the ▲ key to display the screen on the right and press the ENTER key. The analog output hold value setting screen appears.	<div style="border: 1px solid black; padding: 2px;">AO HOLD (ERROR)</div> <div style="border: 1px solid black; padding: 2px;">OUTPUT SELECT</div>
(3)	▲ ENTER	Use the ▲ key to select the hold value. Press the ENTER key to set the value.	<div style="border: 1px solid black; padding: 2px;">OUTPUT SELECT</div> <div style="border: 1px solid black; padding: 2px;">0%</div>
(4)	ENTER	Press the ENTER key.	<div style="border: 1px solid black; padding: 2px;">OUTPUT SELECT</div> <div style="border: 1px solid black; padding: 2px;">0%</div>
(5)		The display returns to the screen on the right.	<div style="border: 1px solid black; padding: 2px;">AO HOLD (ERROR)</div> <div style="border: 1px solid black; padding: 2px;">OUTPUT SELECT</div>

9.2.15 Setting of hold setting value (error hold)

Description





















- Using this function, you can set the output value of analog output signal to an arbitrary value when the analog output hold function (error hold) is enabled.
- This function is enabled if “Setting value” is set at “9.2.14 Hold value setting (error hold).”
- Set the output value of analog output signal as a percentage (%) of the full-scale value of the display range. 0% is equivalent to 0 vol% (4 mA/0 V) and 100 % is to the full-scale value (20 mA/1 V).
- Settable range: 0 to 100 %

Procedure	Operation (example)	Setting the output value of analog output hold to “000%”	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	Press the  key to display the screen on the right and press the  key. The hold setting value setting screen appears.	
(3)	  	Use the  and  key to set the hold value. Press the  key to set the value.	
(4)		Press the  key.	
(5)		The display returns to the screen on the right.	

9.2.16 Setting of key lock

Description















- Authorized person can set if the key lock is valid or invalid using this function. You need a “password” to make a setting if the key lock is valid or invalid.
- If the key lock is valid, you cannot make settings and manual operation (manual calibration, manual broke down, etc.). However, you can see the screen transition and set values.

Procedure	Operation (example)	Setting the key lock to valid (Password is assumed to be “0123”).	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)		Use the  key to select the key lock valid (YES) or invalid (No).	
(3)		Press the  key.	
(4)	 	Use the  key and the  key to input the password.	
(5)		Press the  key.	
(6)		Press the  key to return to the screen on the right.	

9.2.17 LCD brightness adjustment

Description















- You can adjust the brightness of the screen (LCD) using this function.
- Settable range: 0 to 100 %

Procedure	Operation (example)	Setting the brightness of the screen (LCD)	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	 	<p>The LCD brightness adjustment screen appears.</p> <p>Switch between “DOWN” and “UP” with the  key.</p> <p>Use the  key to adjust the brightness.</p> <p>Use the both key to adjust the brightness that sees easily.</p>	
(3)	 	<p>Press the  key to set the value.</p> <p>Press the  key.</p>	
(4)		The display returns to the screen on the right.	

9.2.18 Setting of automatic OFF time

Description

















- You can set the time for automatically turning off the backlight of the LCD (screen) using this function.
When the time set for turning off the backlight elapses after the last operation, the backlight is turned off.
(Press any key to turn on the backlight.)
If 00 seconds is set, the backlight is not turned off.
- Settable range: 0 to 99 min.

Procedure	Operation (example)	Setting the time for automatically turning off the backlight to 10 minutes	
	Key operation	Description	Displayed message (LCD)
(1)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(2)	  	Use the  and  key to set the automatic OFF time. Press the  key to set the value.	
(3)		Press the  key.	
(4)		The display returns to the screen on the right.	

9.2.19 Adjustment screen for analog output 0%

Description






















- You can adjust the analog output 0% using this function.

Procedure	Operation (example)	Adjusting the analog output 0% (4 mA)	
	Key operation	Description	Displayed message (LCD)
(1)		Connect the ammeter to the analog output terminals (5) – (6).	
(2)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(3)		Press the  key. The analog output 0% adjustment screen appears.	
(4)	 	Adjust the analog output with the  and  keys. Switch between “DOWN” and “UP” with the  key. Adjust the value to 4 mA with the  key, checking the analog output with the ammeter.	
(5)		Press the  key to set the value. The display returns to the screen on the right.	
(6)		Remove the ammeter connected to the analog output terminals (5) – (6).	

9.2.20 Adjustment screen for analog output 100%

Description

- You can adjust the analog output 100% using this function.

Procedure	Operation (example)	Adjusting the analog output 100% (20 mA)	
	Key operation	Description	Displayed message (LCD)
(1)		Connect the ammeter to the analog output terminals (5) – (6).	
(2)		Display the screen on the right in accordance with the key operation summary and press the  key.	
(3)		Press the  key. The analog output adjustment screen appears.	
(4)	 	Press the  key. Press the  key. The analog output 100% adjustment screen appears.	
(5)	  	Adjust the analog output with the  and  keys. Switch between “DOWN” and “UP” with the  key. Adjust the value to 20 mA with the  key, checking the analog output with the ammeter. Press the  key to set the value.	
(6)		The display returns to the screen on the right.	
(7)		Remove the ammeter connected to the analog output terminals (5) – (6).	

10. MAINTENANCE AND CHECK

10.1 Checking

Please regularly maintenance, check, and use it always good condition.
Perform maintenance and check once every year or 2, or at time of furnace check.

	Items for check	Recommended interval, method of checking, remedy for abnormalities, etc.
Daily inspection	Span, zero calibration	Calibrate once every week ((Refer to Chapter 7. "CALIBRATION"))
	Deterioration of packings and O-rings	If deteriorated, replace with new ones.
	Check for loose cable ground	Retighten
	Check the remain pressure in the calibration gas cylinder	Check the amount using primary pressure.
Periodic inspection	Clogging or corrosion of flow guide tubes	Remove the flow guide tube from the furnace wall, remove the detector and wash the flow guide tube with water.
	Clogging or corrosion of ejector type sampling prove	Remove the ejector from the furnace wall, disassemble the prove and wash it with water.
	Clogging of air outlet of ejectors	Remove the ejector from the furnace wall and clean the air outlet located in the heat insulation layer of the furnace wall.

10.2 Consumable parts

No.	Product name	Part number for order (Code to order)
1	Ceramic filter	*ZZPZFK4-TK750201P1
2	O-ring for detector	*ZZPZFK4-8552836

10.3 Spare parts


No.	Product name	Code to order
3	Replacement detector	Depends on type designation. See "11.2 Code symbols"
4	Flow guide tube	*ZZP-TK□ See [INZ-TN5ZFK8-E] for details.

10.4 Replacement of fuse

If a fuse blows, turn off the power switch, and replace the fuse after investigating the cause. Open the front door and you can see the two fuses. The upper fuse is for protection of the converter circuit and the lower one is for protection of the heater. Take care that these fuses are different each other in the rated current.

To replace the fuse, insert a flathead screwdriver or coin into the fuse cap and turn it to the left while pressing it in order to remove the cap and replace the fuse.

Put the cap on the fuse and turn it to the right to fix it.



The specifications of the fuse

	Specifications
For converter circuit	$\Phi 5 \times 20$ mm 0.5 A (Example: 0213, 0.5 A, manufactured by Littelfuse)
For heater	$\Phi 5 \times 20$ mm 2.5 A (Example: 0213, 2.5 A, manufactured by Littelfuse)

Note: Use time-lag fuses.

10.5 Troubleshooting

Symptoms	Probable causes	Checking methods (normal value)	Remedy
No display	Converter fuse blown out	Check the fuse and supply voltage specification.	Replace fuse Check Power supply voltage
Indication does not change or slow response	Filter and/or flow guide tube clogged	Visual check of filter and flow guide tube for contamination or clogging. Check for loosen and gas leaks at piping connections and mounting place of detector.	Clean or replace filter Tighten pipe connections
	Detector element deterioration	Change over between zero and span gas and check if 5 minutes or longer is needed for 90% response.	Replace detector element
	Decrease in flow velocity of exhaust gas	Check response to process gas after shutting down calibration gas. Move the direction (mounting position) of "arrow" of the flow guide slightly.	Increase process gas Flow into the flow guide tube.
Temperature alarm continues for more than 10 min. after power switched ON	Break of wiring Wrong wiring Source voltage is too low.	Ohmic check of wiring Wiring check Check of supply voltage specification	Replacement Correct wiring Check supply voltage
	Break of thermocouples	Ohmic check	Replace detector element
	Blown heater fuse	Ohmic check of fuse	Replace fuse
	Break in detector heater	Check heater resistance 50 to 55Ω for 115V, 200 to 250Ω for 220V (Excluding wiring resistance)	Replace detector element
Automatic calibration is not possible	Difference between calibration gas concentration and its setting	Check the set value for calibration gas concentration.	Set proper value (Refer to "8.1.7")
	Wrong parameters setting	Check automatic calibration intervals.	<ul style="list-style-type: none"> Set proper parameters
	The calibration is prohibited in the contact input of the external terminal block.	Check if the calibration is not prohibited in the contact input of the external terminal block.	<ul style="list-style-type: none"> Set proper parameters Correct wiring
	The heater is set to off at the contact input of the external terminal block.	Check if the heater is set to off at the contact input of the external terminal block.	<ul style="list-style-type: none"> Set proper parameters Correct wiring
Zero and/or span alarm	Difference between calibration gas concentration and its setting or misconnection between zero and span gas	Check the set value for calibration gas concentration.	<ul style="list-style-type: none"> Set proper value
		Check piping.	<ul style="list-style-type: none"> Correct wiring
Indication too high or too low	Loose flange and its surroundings Deteriorated O-rings	Check for gas leaks in detector and mounting part of flow guide tube flange.	<ul style="list-style-type: none"> Tighten mounting screws Replace detector element
		Check for leaks from the outside.	<ul style="list-style-type: none"> Seal
	Detector is faulty.	Check for gas leaks at calibration gas inlet. Check detector element voltage (mV) for higher or lower than other detector when flowing zero gas. (See "6.5 Oxygen detector standard output voltage")	<ul style="list-style-type: none"> Tighten connectors Replace detector element
	Abnormal detector element temperature	Refer to check items for detector temperature alarm described above.	<ul style="list-style-type: none"> Replace detector element
	Indication difference between dry and wet base measurement	Oxygen concentration is higher in dry base.	<ul style="list-style-type: none"> Normal

Symptoms	Probable causes	Checking methods (normal value)	Remedy
Disconnection detection error	Break of thermocouples Break of detector element Wrong wiring	Ohmic check of wiring Wiring check	<ul style="list-style-type: none"> • Replace the defective parts. • Correct wiring • Turn on/off the power supply.
Range cannot be switched.	“Range setting” is set in the contact input setting.	Check if “Range setting” is set in the contact input setting.	Cancel “Range setting” in the contact input setting.

11. SPECIFICATIONS

11.1 Specifications

General Specifications

- **Measuring object** : Oxygen in noncombustible gas
- **Measuring method** : Directly insert type zirconia system
- **Measuring range** : 0 to 2 ... setting range at option 2 in 50 vol% O₂ (in 1 vol% O₂ steps)
- **Repeatability** : Within ±0.5%FS
- **Linearity** : Within ±2%FS
- **Response time** : Within 4 to 7 sec, for 90% (from calibration gas inlet)
- **Warmup time** : More than 10 min
- **Analog output** : 4 to 20mA DC (allowable load resistance 500Ω or less) or
0 to 1V DC (output resistance 100Ω or more)
- **Power supply** : Rated voltage;
100 to 120V AC (operating voltage 90 to 132V AC)
200 to 240V AC (operating voltage 190 to 264V AC)
Rated frequency; 50/60Hz
- **Power consumption** : Maximum 240VA (Detector: approx. 200VA, Converter: approx. 40VA)
Normal 70VA (Detector: approx. 50VA, Converter: approx. 20VA)

Detector Specifications (ZFK)

- **Measured gas temperature:**
Flow guide tube system; -20 to +600°C (for general-use, corrosive gas)
Ejector system; -20 to +1500°C (for high-temperature gas)
-20 to +800°C (for general-use)
- **Measured gas pressure:**
-3 to +3kPa
- **Flow guide tube** :
 - With or without blowdown nozzle
Flange; JIA5K 65A FF
Insertion length; 0.3, 0.5, 0.75, 1m
 - For high particulate gas (with blowdown nozzle)
With or without cover
Flange; JIS5K 80A FF
Insertion length; 0.3, 0.5, 0.75, 1m
- **Ejector** : Probe for guiding measured gas to detector
Flange; JIS10K 65A RF
Insertion length; 0.5, 0.75, 1, 1.5m (according to customer's specification)
- **Operating temperature** :
-10 to +60°C for Primary detecting element -5 to +100°C for detector
125°C or less at detector flange surface with power applied
- **Storage temperature** : Detector: -20 to +70°C
Ejector: -10 to +100°C
- **Structure** : Dust/rain-proof structure (IEC IP66 equivalent, except the filter part at the tip)
Use a heat insulation cover in cold climates (as specified)
- **Filter** : Alumina (filtering accuracy 50μm) and quartz paper

-
- **Main materials of gas-contacting parts:**
 Detector; Zirconia, SCS14 (SUS316 equivalent), platinum, SUS304
 Flow guide tube; SUS304 or SUS316
 Ejector (general use); SUS316, SUS304
 Ejector; (for high temperature) SiC, SUS316, SUS304
 - **Calibration gas inlet** : $\phi 6$ mm tube join, $\phi 1/4$ -inch tube join, or ball valve (as specified)
 - **Reference air inlet (option):**
 $\phi 6$ mm tube join or $\phi 1/4$ -inch tube join (as specified)
 It is used when reference oxygen gas concentration changes
 - **Detector mounting** : Horizontal plane $\pm 45^\circ$, ambient air should be clean.
 - **Outer dimensions** : (L \times max. dia.) 210mm \times 100mm (detector)
 - **Mass (approx.) {weight}:**
 Detector; 1.6kg
 Ejector; 15kg (insertion length 1m)
 Flow guide tube (general-use, 1m); 5kg
 - **Finish color** : Silver and SUS metallic color
 - **Ejector air inlet flow rate:**
 5 to 10 L/min
 - **Calibration gas flow** : 1.5 to 2 L/min
 - **Blowdown air inlet pressure:**
 200 to 300kPa
 - **Ejector exhaust gas processing:**
 Returned to furnace and flue
 - **Heater temperature drop alarm output (ejector):**
 Alarm output when below 100 $^\circ\text{C}$ Mechanical thermostat N.O. (1a) contact, 200V AC, 2A

Converter specification (ZKM)

- **Concentration value indication:**
 Digital indication in 4 digits
 - **Contact output signal:**
 - (1) Contact specification; 6 points, 1a 250V AC/3A or 30V DC/3A
 - (2) Contact function;
 - Under maintenance
 - Under blowdown Note3)
 - Span calibration gas valve
 - Zero calibration gas valve
 - Instrument anomalies Note1)
 - Alarm Note2)
- Note1) The following Instrument errors (1) Thermocouples break (2) Sensor break (3) Temperature fault (4) Calibration fault (5) Zero/span fault (6) Output error the contact ON
- Note2) Alarm selects just one as mentioned below (1) High (2) Low (3) H/L (4) HH (5) LL, it turns ON while operating.
- Note3) Under blow down, it is available in case of option, and it turns ON while operating.

-
- **Contact input signal:**
 - (1) Contact specification; 3points (the following option)
ON; 0V (10mA or less), OFF; 5V
 - (2) Contact function;
 - External hold
 - Calculation reset
 - Heater OFF
 - Blow down (option)
 - Inhibition of calibration
 - Calibration start
 - Range change
 - **Calibration method:**
 - (a) Manual calibration with key operation
 - (b) Auto. calibration (option)
Calibration cycle; 00 day 00 hour to 99 days 23 hours
 - (c) All calibration
 - **Calibration gas** :
 - Settable range
Zero gas; 0.010 to 25.00% O₂
Span gas: 0.010 to 50.00% O₂
 - Recommended calibration gas concentration
Zero gas; 0.25 to 2.0% O₂
Span gas; 20.6 to 21.0% O₂ (oxygen concentration in the air)
 - **Blowdown (optein)** : A function for blowing out dust with compressed air that has deposited in the flow guide tube. Blowdown can be performed only for a predetermined time and at predetermined intervals.
Blowdown cycle; 00 hour 00 minute to 99 hours 59 minutes
Blowdown time; 0 minute 00 second to 0 minutes 999 seconds
 - **Output signal hold** : Output signal is held during manual/auto calibration, blowdown, sensor recovery processing, warm-up, PID auto tuning, and while maintenance mode setting is "available". The hold function can also be released.
 - **Communication function:**
RS232C (MODBUS) standard specification
RS485 (MODBUS) (option)
 - **Combustion efficiency display (option):**
When you select this display, "rich mode display" will be simultaneously displayed. This function calculates and displays combustion efficiency from oxygen concentration and measured gas temperature. Thermocouple (R) is required for temperature measurement.
 - **Operating temperature:**
-20 to +55°C
 - **Operating humidity** : 95% RH or less, non condensing
 - **Storage temperature** : -30 to +70°C
 - **Storage humidity** : 95% RH or less, non condensing
 - **Outer dimensions (H × W × D):**
182 × 163.5 × 70.6mm (Bench type)
 - **Mass {weight}** : Approx. 2kg (excluding cable and detector)
 - **Mounting method** : Mounted flush on panel
-

11.2 Code symbols

<Replacement Detector element>

Power supply	Code symbols
100 to 120V AC	ZFK8YY15-0Y0YY-0YY
200 to 240V AC	ZFK8YY35-0Y0YY-0YY

Fuji Electric Co., Ltd.

International Sales Div

Sales Group

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome,
Shinagawa-ku, Tokyo 141-0032, Japan

<http://www.fujielectric.com>

Phone: 81-3-5435-7280, 7281 Fax: 81-3-5435-7425

<http://www.fujielectric.com/products/instruments/>
