

The following table provides a drawing cross-reference for Fuji Electric's **FRENIC-Mini** open chassis drives.

<i>FRENIC-Mini</i> (Open Chassis)			
Voltage/Phase	Hp	Drive Model Number	Drawing Number
115V 1-phase	1/8	FRNF12C1S-6U	ROA701201
	1/4	FRNF25C1S-6U	
	1/2	FRNF50C1S-6U	ROA701204
	1	FRN001C1S-6U	ROA701206
230V 1-phase	1/8	FRNF12C1S-7U	ROA701200
	1/4	FRNF25C1S-7U	
	1/2	FRNF50C1S-7U	ROA701202
	1	FRN001C1S-7U	ROA701208
	2	FRN002C1S-7U	ROA701210
	3	FRN003C1S-7U	ROA701211
230V 3-phase	1/8	FRNF12C1S-2U	ROA701200
	1/4	FRNF25C1S-2U	
	1/2	FRNF50C1S-2U	ROA701202
	1	FRN001C1S-2U	ROA701205
	2	FRN002C1S-2U	ROA701209
	3	FRN003C1S-2U	
	5	FRN005C1S-2U	ROA701211
460V 3-phase	1/2	FRNF50C1S-4U	ROA701203
	1	FRN001C1S-4U	ROA701207
	2	FRN002C1S-4U	ROA701209
	3	FRN003C1S-4U	
	5	FRN005C1S-4U	ROA701211

Notes:

1. For additional product information please see the *FRENIC-Mini* instruction manual INR-SI47-1205-E.

The following table provides a drawing cross-reference for Fuji Electric's **FRENIC-Mini** drives including the appropriate NEMA 1

<i>FRENIC-Mini</i> (Including NEMA 1 Kit)				
Voltage/Phase	Hp	Drive Model Number	NEMA 1 Kit Model Number	Drawing Number
115V 1-phase	1/8	FRNF12C1S-6U	NEMA1-0.2C1-6	ROA701213
	1/4	FRNF25C1S-6U	NEMA1-0.2C1-6	
	1/2	FRNF50C1S-6U	NEMA1-0.4C1-6	ROA701216
	1	FRN001C1S-6U	NEMA1-0.75C1-6	ROA701218
230V 1-phase	1/8	FRNF12C1S-7U	NEMA1-0.2C1-2	ROA701212
	1/4	FRNF25C1S-7U	NEMA1-0.2C1-2	
	1/2	FRNF50C1S-7U	NEMA1-0.4C1-2	ROA701214
	1	FRN001C1S-7U	NEMA1-0.75C1-7	ROA701220
	2	FRN002C1S-7U	NEMA1-1.5C1-7	ROA701222
	3	FRN003C1S-7U	NEMA1-3.7C1-2	ROA701223
230V 3-phase	1/8	FRNF12C1S-2U	NEMA1-0.2C1-2	ROA701212
	1/4	FRNF25C1S-2U	NEMA1-0.2C1-2	
	1/2	FRNF50C1S-2U	NEMA1-0.4C1-2	ROA701214
	1	FRN001C1S-2U	NEMA1-0.75C1-2	ROA701217
	2	FRN002C1S-2U	NEMA1-2.2C1-2	ROA701221
	3	FRN003C1S-2U	NEMA1-2.2C1-2	
460V 3-phase	5	FRN005C1S-2U	NEMA1-3.7C1-2	ROA701223
	1/2	FRNF50C1S-4U	NEMA1-1.0C1-4	ROA701215
	1	FRN001C1S-4U	NEMA1-0.75C1-4	ROA701219
	2	FRN002C1S-4U	NEMA1-2.2C1-2	ROA701221
	3	FRN003C1S-4U	NEMA1-2.2C1-2	
	5	FRN005C1S-4U	NEMA1-3.7C1-2	ROA701223

Notes:

1. For additional product information please see the *FRENIC-Mini* instruction manual INR-SI47-1205-E.